

BS1000 device logging codes

Rule	Device	Code	Description
Startup	0	0	startup device
Access	0	code	open new session code: 0 = success, 1 = failed
Access	0	2	log in failed
Time	0	0	time set by network time server
Time	0	1	time query timed out
Time	0	2	time server not resolved
Time	1	0	time set by usb
Startup	1	0	reset device to default settings
DHCP	0	0	dhcp configured
rulenb	device	0	rule executed with beep
rulenb	device	1	rule http address unresolved
rulenb	device	2	rule http request timeout
rulenb	device	3	rule hhttp request parse error
rulenb	device	4	rule hhttp request cannot connect
rulenb	device	5	rule hhttp request timeout
rulenb	device	6	rule hhttp request timeout
rulenb	device	7	rule hhttp request timeout
rulenb	device	8	rule hhttp request closed unexpected
rulenb	device	21	rule condition parse error
rulenb	device	22	rule condition parse error
rulenb	device	code	smtp server or http server result code for rule
rulenb	device	1	no mail server address
rulenb	device	2	cannot connect to mailserver